





LEVIOR s.r.o.  
Tovačovská 3488/28  
750 02 Přerov  
Czech Republic  
CZ61973939

## Instructions for use –180° grass shears

(45012)



- rotary 0 – 360°
- total length 37 cm
- blades locking for safety use
- use: grass shears allow easy & precise lawn edging



THE IMPORTER: LEVIOR s.r.o.

## **Warnings and precautions**

---

Read all instructions before using this tool!

1. Keep workspace clean. Disorder in the workspace leads to injuries.
2. Keep away from the child.
3. Do not expose the scissors to rain.
4. Store the shears in a dry place.
5. Do not modify this tool or use this tool for a purpose for which it was not intended
6. Handle shears with care. Keep them sharp and clean for better and safer performance.
7. The handle must be always clean, dry and free of oil and grease.
8. Stay alert during working. Watch what you are doing, use common sense.
9. Damaged parts should be properly repaired or replaced by a qualified technician.
10. Do not use the shears if you are under the influence of alcohol or drugs.
11. The blades are very sharp. Keep your hands away from the blades.
12. Check the workspace. Make sure there are no wires within reach before cutting.
13. When working with scissors, make sure the blades are straight. Use adequate pressure that will allow the scissors to function properly.